

## **N9H20 NVT Loader Reference Guide**

### **Document Information**

<b>Abstract</b>	N9H20 NVT Loader Reference Guide
<b>Apply to</b>	N9H20 series

*The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.*

*Nuvoton is providing this document only for reference purposes of microcontroller and microprocessor based system design. Nuvoton assumes no responsibility for errors or omissions.*

*All data and specifications are subject to change without notice.*

For additional information or questions, please contact: Nuvoton Technology Corporation.

[www.nuvoton.com](http://www.nuvoton.com)

<b>1</b>	<b>GENERAL DESCRIPTION</b>	<b>3</b>
1.1	General Description	3
<b>2</b>	<b>INTRODUCTION</b>	<b>4</b>
2.1	Features	4
2.2	Execution Flow	5
2.3	Memory Map	5

# 1 General Description

## 1.1 General Description

Generally, there are 3 stages to launch the user's application code as power on N9H20 system. These booting stages are IBR, NAND/SD Loader and NVT Loader. NVT loader acts as the 3<sup>rd</sup> stage to load kernel. NVT Loader is used to load Linux kernel to memory address 0 and make it running well. It can load kernel binary file from SD drive or NAND drive. As power on, IBR is the first execution code that detects the DRAM memory type and size and configures DRAM controller. After that, IBR will parse SD Loader or NAND Loader on SD card or NAND flash system area. If they exist, IBR will load the SD Loader or NAND Loader to SDRAM memory address depends on different chip type. After that, it passes the CPU control to SD Loader or NAND Loader. SD/NAND Loader sets the desired system clock, memory clock, the SDRAM timing and clock skew respectively. After setting the correct memory access timing, SD/NAND Loader will parse the system area of SD card or NAND device. Basically, the system area is used to store SD/NAND Loader image, logo image and NVT Loader. SD/NAND Loader will load the logo image and NVT Loader to the addresses that recorded in system area. After NVT Loader is loaded to the executed address, SD/NAND Loader passes the CPU control to NVT Loader. There is no code size constraint on NVT Loader. It provides more powerful functions, such as file system access, playback motion animation and USB mass-storage. NVT Loader loads next image from the user area of SD card or NAND flash. After NVT Loader loading the execution image, it passes the CPU control to the execution image.

The sequence for loading the kernel from power on was showed as following figure.




Figure 1-1: Sequence for loading kernel

## 2 Introduction

NVT Loader acts as the 3<sup>rd</sup> stage to load kernel or sample program. Due to it does not have code size limitation, NVT Loader could provide more features than SD/NAND Loader.

### 2.1 Features

- Supports FAT file system on NAND flash or external SD card.
- Supports USBD mass storage connected with PC.
- Supports AVI playback

## 2.2 Execution Flow

There are two mainly branches to load kernel from on board NAND flash or external SD card. The following figure shows the control flow of NVT Loader.




Figure 2-1: Execution Flow

NVT Loader follows following steps to update files or launch next image.

1. Initialize system and detect battery level. If the detected battery voltage is lower than the specified level, shut down the system immediately.
2. Initialize panel if necessary. The frame buffer address always fixed at address 0x500000. The address follows Linux driver's setting to avoid flash or un-continuous symptom as starting up Linux kernel.\
3. Mount SD or NAND device. If it is unknown device, partition and format the device.
4. Detect USB cable plug in or not. If USB cable plug in, run mass-storage function. Then user can update image or AVI file to the root directory of disk label "SD1-1" or "NAND1-1" through PC. After update image done, user can plug out the USB cable. NVT Loader will disable mass-storage function and enter step 6.
5. Play AVI file with file name "movie.avi" if the file exists.
6. Load next image with file name "conprog.bin" if the file exists. After this action done, pass the CPU control to next image.

## 2.3 Memory Map

Scatter description loading file describes the memory map in load and execution view. NVT Loader should be loaded to address 0x600000 or 0x800000 dependent on N9H20 series by using different Scatter file. The following table and figure show the execution view of Loader and NVT Loader.

	SD/NAND Loader Address	NVT Loader Address	Logo
<b>N9H20K1</b>	0x180000	Undefined	Undefined
<b>N9H20K3</b>	0x700000	0x600000	0x500000
<b>N9H20K5</b>	0x900000	0x800000	0x500000

Table 2-1: Execution address for vary chip type




Figure 2-2: NVT-Loader Execution View

**Revision History**

Date	Revision	Description
2021.06.21	1.10	Revision
2018.05.02	1.00	Initially issued.

### **Important Notice**

**Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".**

**Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.**

**All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.**

---

*Please note that all data and specifications are subject to change without notice.  
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.*